

Replacement Parts



Replacement Overloads 3 Phase Starters (3 Pole Thermal Overload Relays Class 10)

Overload Code	Range	Part No.	For Use With Contactor Amp Range
R23	0.8 - 1.2	RW27-2D3-D012	ESW-B9 - ESW-B38
R24	1.2 - 1.8	RW27-2D3-D018	ESW-B9 - ESW-B38
R25	1.8 - 2.8	RW27-2D3-D028	ESW-B9 - ESW-B38
R26	2.8 - 4.0	RW27-2D3-U004	ESW-B9 - ESW-B38
R27	4.0 - 6.3	RW27-2D3-D063	ESW-B9 - ESW-B38
R28	5.6 - 8.0	RW27-2D3-U008	ESW-B9 - ESW-B38
R29	7 - 10	RW27-2D3-U010	ESW-B9 - ESW-B38
R30	8 - 12.5	RW27-2D3-D125	ESW-B9 - ESW-B38
R32	11 - 17	RW27-2D3-U017	ESW-B9 - ESW-B38
R33	15 - 23	RW27-2D3-U023	ESW-B9 - ESW-B38
R34	22 - 32	RW27-2D3-U032	ESW-B9 - ESW-B38
R35	32 - 40	RW27-2D3-U040	ESW-B9 - ESW-B38
R70	25 - 40	RW67-5D3-U040	ESW-B40
R71	32 - 50	RW67-5D3-U050	ESW-B50 - ESW-B80
R72	40 - 57	RW67-5D3-U057	ESW-B50 - ESW-B80
R74	57 - 70	RW67-5D3-U070	ESW-B50 - ESW-B80
R43	63 - 80	RW117-1D3-U080	ESW-95 - ESW-105
R44	75 - 97	RW117-1D3-U097	ESW-95 - ESW-105
R45	90 - 112	RW117-1D3-U112	ESW-95 - ESW-105



BRB Coil

Replacement Coils

Model No.	208/230V Part No.	460V Part No.	120V Part No.	24VAC Part No.
ESW-B9, B12, B25, B32, B38	BRB-38V24	BRB-38D39	BRB-38D15	BRB-38D02
ESWB-40, B50, B65, B80	BRB-80V24	BRB-80D39	BRB-80D15	BRB-80D02
ESW-95, 105	BCA-105V24	BCA-105V47	BCA-105V18	BCA-105V04

Replacement Parts

Replacement Parts



Replacement Overloads 1 Phase Starters
(2 Pole Thermal Overload Relays Class 10)

Overload Code	Range	Part No.	For Use With Contactor Amp Range
RM23	0.8 - 1.2	RW27-2D2-D012	ESWS-B9 - ESWS-B38
RM24	1.2 - 1.8	RW27-2D2-D018	ESWS-B9 - ESWS-B38
RM25	1.8 - 2.8	RW27-2D2-D028	ESWS-B9 - ESWS-B38
RM26	2.8 - 4.0	RW27-2D2-U004	ESWS-B9 - ESWS-B38
RM27	4.0 - 6.3	RW27-2D2-D063	ESWS-B9 - ESWS-B38
RM28	5.6 - 8.0	RW27-2D2-U008	ESWS-B9 - ESWS-B38
RM29	7 - 10	RW27-2D2-U010	ESWS-B9 - ESWS-B38
RM30	8 - 12.5	RW27-2D2-D125	ESWS-B9 - ESWS-B38
RM32	11 - 17	RW27-2D2-U017	ESWS-B9 - ESWS-B38
RM33	15 - 23	RW27-2D2-U023	ESWS-B9 - ESWS-B38
RM34	22 - 32	RW27-2D2-U032	ESWS-B9 - ESWS-B38
RM35	32 - 40	RW27-2D2-U040	ESWS-B9 - ESWS-B38
RM70	25 - 40	RW67-5D2-U040	ESWS-B40
RM71	32 - 50	RW67-5D2-U050	ESWS-B50



BRB Coil

Replacement Coils

Model No.	208/230V Part No.	120V Part No.
ESWS-B9, B12, B25, B32, B38	BRB-38V24	BRB-38D15
ESWS-B40, B50, B65, B80	BRB-80V24	BRB-80D15

Replacement Parts