

## ER-604W

### SHOULDER MEGAPHONE 6W



The ER-604W is a compact, lightweight shoulder-type megaphone with whistle signal. It's close-talking microphone has a handy-to-operate volume control and press-to-talk switch. External microphone inputs on the unit's rear panel can accept an optional microphone or a headset microphone for hands-free use. In addition, an AUX (auxiliary) input can accept a CD, MD, or cassette player.

### Key features

## Specifications

\* 0 dB = 1 V

Power Source	R6 battery x 8 (12 V DC) 12 V DC/0.8 A or more (AC adapter or DC power supply unit usable)
Rated Output	6 W
Maximum Output	10 W
Signal Sound	Whistle, push switch activation
Battery Life	Voice: Approx. 10 hours (R6P manganese dioxide battery use) Whistle: Approx. 30 minutes (continuous use)
Audible Range	Voice: 160 m (under noise level of 55 dB) Whistle: 160 m (under noise level of 55 dB)
Microphone	Close-talking type, press-to-talk switch, volume control Fixed to the microphone hanger on the unit's top panel
Input	MIC 1: -40 dB*, 1.5 k $\Omega$ , $\varnothing$ 6.3 phone jack MIC 2: -18 dB*, 3 k $\Omega$ , $\varnothing$ 3.5 mini jack, phantom powering AUX (auxiliary): -12 dB*, 18 k $\Omega$ , $\varnothing$ 3.5 mini jack External power supply: 12 V DC Note: MIC1, 2, and AUX inputs can be used at the same time. However, their individual volume cannot be adjusted as the unit's volume control is common to those inputs.
Other Function	Voice switch (functions to activate the unit with external input signals, and to make the unit in stand-by status with no external signal.) Battery check
Operating Temperature	-10 °C to +40 °C
Finish	Body, microphone: ABS resin, off-white Shoulder pad, belt: Black
Dimensions	102 (W) x 258 (H) x 216 (D) mm (excluding shoulder belt)
Weight	1.6 kg (without batteries)
Included Accessories	$\varnothing$ 3.5 mini plug x 1, External power supply cord (1 m) x 1
Optional Accessories	Headset microphone: WH-4000A, WH-4000H Dynamic microphone: DM series Speaker stand: ST-16A

### [Notes]

- Batteries are optional.
- Do not use a car's starting battery, as its voltage is too high. Doing so may cause the megaphone to malfunction.
- Battery Life assumes the megaphone is used for 30 minutes per day.
- Audible Range assumes the megaphone uses new batteries and is operated on a quiet street. It varies depending on factors such as battery consumption, ambient noise, wind direction, and obstacles.

## Dimensions

